

---

## **IBIS/HSPICE Model Quality Report**

**Design ID- u48b**

**Description-1Gb DDR-2 SDRAM**

**Marketing device name(s):** MT47H256M4HQ, MT47H128M8HQ, MT47H64M16HR, MT47H256M4HQ-IT, MT47H128M8HQ-IT, MT47H64M16HR-IT, MT47H256M4U48B, MT47H128M8U48B, MT47H64M16U48B, MT47H256M4U48B-IT, MT47H128M8U48B-IT, MT47H64M16U48B-IT,

**Zip File Name:**u48b\_ibis.zip, u48b\_bd\_ibis.zip, u48b\_it\_ibis.zip, u48b\_bd\_it\_ibis.zip

**IBIS File name:** u48b.ibs, u48b\_bd.ibs, u48b\_it.ibs, u48b\_bd\_it.ibs **File rev:** 2.1

**HSPICE File name:** u48b\_hspice.zip **File rev:** 2.1

**EBD file name (if applicable):** **File rev:**

**Die Rev:** E

**Date:** June 21, 2007

**Datasheet Link (include datasheet link from micron.com)**

<http://download.micron.com/pdf/datasheets/dram/ddr2/1GbDDR2.pdf>

E-mail at [modelsupport@micron.com](mailto:modelsupport@micron.com) for questions regarding Quality Report

---

### **IBIS Quality Summary**

1. ☒ Include the IBIS Quality Summary information in the Quality report. For details on IBIS Quality check the quality specification and quality checklist on IBIS quality webpage  
[http://www.vhdl.org/pub/ibis/quality\\_wip/](http://www.vhdl.org/pub/ibis/quality_wip/)

Include the Ibis quality levels for all components and models in the Ibis file.

IIQ SUMMARY Overall Quality of component and models Level 2b

|

IIQ Level 0 - 0 errors 0 warnings

IIQ Level 1 - All checks done for completeness and correctness

IIQ Level 2 - HSPICE Correlation

IIQ Buffer

DQFULL\_533/DQFULL\_ODT50\_533/DQFULL\_ODT75\_533/DQFULL\_ODT150\_533:

Quality level 2b

IIQ Buffer

DQFULL\_667/DQFULL\_ODT50\_667/DQFULL\_ODT75\_667/DQFULL\_ODT150\_667:

Quality level 2b

IIQ Buffer

DQFULL\_1066/DQFULL\_ODT50\_1066/DQFULL\_ODT75\_1066/DQFULL\_ODT150\_1066:

Quality level 2b

IIQ Buffer  
DQHALF\_533/DQHALF\_ODT50\_533/DQHALF\_ODT75\_533/DQHALF\_ODT150\_533:  
Quality level 2b  
IIQ Buffer  
DQHALF\_667/DQHALF\_ODT50\_667/DQHALF\_ODT75\_667/DQHALF\_ODT150\_667:  
Quality level 2b  
IIQ Buffer  
DQHALF\_1066/DQHALF\_ODT50\_1066/DQHALF\_ODT75\_1066/DQHALF\_ODT150\_1066:  
Quality level 2b

IIQ Buffer RDQS\_FULL\_533/RDQS\_HALF\_533: Quality level 2b  
IIQ Buffer RDQS\_FULL\_667/RDQS\_HALF\_667: Quality level 2b  
IIQ Buffer RDQS\_FULL\_1066/RDQS\_HALF\_1066: Quality level 2b  
IIQ Buffer DM\_INPUT\_533/DM\_ODT50\_533/DM\_ODT75\_533/DM\_ODT150\_533: Quality level 2b  
IIQ Buffer DM\_INPUT\_667/DM\_ODT50\_667/DM\_ODT75\_667/DM\_ODT150\_667: Quality level 2b  
IIQ Buffer DM\_INPUT\_1066/DM\_ODT50\_1066/DM\_ODT75\_1066/DM\_ODT150\_1066: Quality level 2b

|  
IIQ Level 1  
| All Level 1 checks performed and are either OK or NA  
|

IIQ Level 2  
| Using VT IBIS Data compared to source hspice models  
|

IIQ Level 2b  
| C\_comp laboratory and hspice correlation  
|

IIQ BEGIN IBIS Quality Checklist

IIQ FILE: u48b.ibs, u48b_bd.ibs, u48b_it.ibs, u48b_bd_it.ibs	IQ Level: 1
IIQ COMPONENT: MT47H256M4HQ	IQ Level: 1
IIQ COMPONENT: MT47H256M4HQ_CLP	IQ Level: 1
IIQ COMPONENT: MT47H128M8HQ	IQ Level: 1
IIQ COMPONENT: MT47H128M8HQ_CLP	IQ Level: 1
IIQ COMPONENT: MT47H64M16HR	IQ Level: 1
IIQ COMPONENT: MT47H64M16HR_CLP	IQ Level: 1
IIQ COMPONENT: MT47H256M4HQ_IT	IQ Level: 1
IIQ COMPONENT: MT47H256M4HQ_IT_CLP	IQ Level: 1
IIQ COMPONENT: MT47H128M8HQ_IT	IQ Level: 1
IIQ COMPONENT: MT47H128M8HQ_IT_CLP	IQ Level: 1

---

IIQ COMPONENT: MT47H64M16HR_IT	IQ Level: 1
IIQ COMPONENT: MT47H64M16HR_IT_CLP	IQ Level: 1
IIQ COMPONENT: MT47H256M4U48B	IQ Level: 1
IIQ COMPONENT: MT47H128M8U48B	IQ Level: 1
IIQ COMPONENT: MT47H64M16U48B	IQ Level: 1
IIQ COMPONENT: MT47H256M4U48B_IT	IQ Level: 1
IIQ COMPONENT: MT47H128M8U48B_IT	IQ Level: 1
IIQ COMPONENT: MT47H64M16U48B_IT	IQ Level: 1

IIQ MODEL: DQFULL_533	IQ Level: 2b
IIQ MODEL: DQFULL_533_ODT50	IQ Level: 2b
IIQ MODEL: DQFULL_533_ODT75	IQ Level: 2b
IIQ MODEL: DQFULL_533_ODT150	IQ Level: 2b
IIQ MODEL: DQHALF_533	IQ Level: 2b
IIQ MODEL: DQHALF_533_ODT50	IQ Level: 2b
IIQ MODEL: DQHALF_533_ODT75	IQ Level: 2b
IIQ MODEL: DQHALF_533_ODT150	IQ Level: 2b
IIQ MODEL: RDQS_FULL_533	IQ Level: 2b
IIQ MODEL: RDQS_HALF_533	IQ Level: 2b
IIQ MODEL: DM_INPUT_533	IQ Level: 2b
IIQ MODEL: DM_ODT50_533	IQ Level: 2b
IIQ MODEL: DM_ODT75_533	IQ Level: 2b
IIQ MODEL: DM_ODT150_533	IQ Level: 2b
IIQ MODEL: INPUT_533	IQ Level: 2b
IIQ MODEL: CLKIN_533	IQ Level: 2b

IIQ MODEL: DQFULL_667	IQ Level: 2b
IIQ MODEL: DQFULL_667_ODT50	IQ Level: 2b
IIQ MODEL: DQFULL_667_ODT75	IQ Level: 2b
IIQ MODEL: DQFULL_667_ODT150	IQ Level: 2b
IIQ MODEL: DQHALF_667	IQ Level: 2b
IIQ MODEL: DQHALF_667_ODT50	IQ Level: 2b
IIQ MODEL: DQHALF_667_ODT75	IQ Level: 2b
IIQ MODEL: DQHALF_667_ODT150	IQ Level: 2b
IIQ MODEL: RDQS_FULL_667	IQ Level: 2b
IIQ MODEL: RDQS_HALF_667	IQ Level: 2b
IIQ MODEL: DM_INPUT_667	IQ Level: 2b
IIQ MODEL: DM_ODT50_667	IQ Level: 2b
IIQ MODEL: DM_ODT75_667	IQ Level: 2b
IIQ MODEL: DM_ODT150_667	IQ Level: 2b
IIQ MODEL: INPUT_667	IQ Level: 2b
IIQ MODEL: CLKIN_667	IQ Level: 2b

---

IIQ MODEL: DQFULL_1066	IQ Level:	2b
IIQ MODEL: DQFULL_667_ODT50	IQ Level:	2b
IIQ MODEL: DQFULL_667_ODT75	IQ Level:	2b
IIQ MODEL: DQFULL_667_ODT150	IQ Level:	2b
IIQ MODEL: DQHALF_1066	IQ Level:	2b
IIQ MODEL: DQHALF_667_ODT50	IQ Level:	2b
IIQ MODEL: DQHALF_667_ODT75	IQ Level:	2b
IIQ MODEL: DQHALF_667_ODT150	IQ Level:	2b
IIQ MODEL: RDQS_FULL_1066	IQ Level:	2b
IIQ MODEL: RDQS_HALF_1066	IQ Level:	2b
IIQ MODEL: DM_INPUT_1066	IQ Level:	2b
IIQ MODEL: DM_ODT50_1066	IQ Level:	2b
IIQ MODEL: DM_ODT75_1066	IQ Level:	2b
IIQ MODEL: DM_ODT150_1066	IQ Level:	2b
IIQ MODEL: INPUT_1066	IQ Level:	2b
IIQ MODEL: CLKIN_1066	IQ Level:	2b
IIQ MODEL: NF_INPUT	IQ Level:	2b


IIQ END IBIS Quality Checklist

### **IBIS MODEL Correlation**

#### **Datasheet Correlation**

1. ☒ For Output model or I/O model compare datasheet IOH/IOL data with Ibis pullup/pulldown data.

## Comparison of JEDEC Spec and IBIS Data (Full Drive)



2. ☒ Compare C\_comp with datasheet Input C. Provide c\_comp comparison table for all models and for all package combinations (i.e x4, x8 and x16)

Insert component name here **MT47H256M4HQ**

		IBIS		Datasheet	
		Min	max	min	max
<b>DQ</b>	C_comp	3.06pF	3.47pF		
	C_package	0.09pF	0.17pF		
	C_total	3.15pF	3.64pF	2.5pF	3.5pF
<b>INPUT</b>	C_comp	1.16pF	1.54pF		
	C_package	0.08pF	0.14pF		
	C_total	1.24pF	1.68pF	1.0pF	1.75pF
<b>CLK</b>	C_comp	1.25pF	1.52pF		
	C_package	0.12pF	0.13pF		
	C_total	1.37pF	1.65pF	1.0pF	2.0pF

Insert component name here **MT47H128M8HQ**

		IBIS		Datasheet	
		Min	max	min	max
<b>DQ</b>	C_comp	3.06pF	3.47pF		
	C_package	0.09pF	0.17pF		
	C_total	3.15pF	3.64pF	2.5pF	3.5pF
<b>INPUT</b>	C_comp	1.16pF	1.54pF		
	C_package	0.08pF	0.14pF		
	C_total	1.24pF	1.68pF	1.0pF	1.75pF
<b>CLK</b>	C_comp	1.25pF	1.52pF		
	C_package	0.12pF	0.13pF		
	C_total	1.37pF	1.65pF	1.0pF	2.0pF

Insert component name here **MT47H64M16HR**

		IBIS		Datasheet	
		Min	max	min	Max
<b>DQ</b>	C_comp	3.06pF	3.47pF		
	C_package	0.12pF	0.18pF		
	C_total	3.18pF	3.65pF	2.5pF	3.5pF
<b>INPUT</b>	C_comp	1.16pF	1.54pF		
	C_package	0.11pF	0.16pF		
	C_total	1.27pF	1.70pF	1.0pF	1.75pF
<b>CLK</b>	C_comp	1.25pF	1.52pF		
	C_package	0.13pF	0.13pF		
	C_total	1.38pF	1.65pF	1.0pF	2.0pF

3. ☐ If slew rate specifications (Rise slew and Fall slew) are available from the datasheet, complete Hspice simulation to generate slew rate data and provide a comparison table.

**Not available**

### Measurement Correlation

1. ☒ For Output model or I/O model compare measured IOH/IOL data with Ibis pullup pulldown data. If the measurement condition is different than Ibis condition, run hspice simulation using the same measurement condition, for example Vcc, temp and process. Include measurement conditions in the pullup/pulldown images.

**Not available**

2. ☒ Compare c\_comp with measured c\_comp. Provide c\_comp comparison table for all models and for all package combinations (i.e x4, x8 and x16)

Insert component name here **MT47H256M4HQ**

		IBIS			Measured		
		min	Typ	max	min	typ	max
<b>DQ</b>	C_comp	3.06pF	3.24pF	3.47pF	NA	NA	NA
	C_package	0.09pF	0.11pF	0.17pF	NA	NA	NA
	C_total	3.15pF	3.35pF	3.64pF	3.21pF	3.28pF	3.48pF
<b>INPUT</b>	C_comp	1.16pF	1.35pF	1.54pF	NA	NA	NA
	C_package	0.08pF	0.1pF	0.14pF	NA	NA	NA
	C_total	1.24pF	1.45pF	1.68pF	1.34pF	1.44pF	1.58pF
<b>CLK</b>	C_comp	1.25pF	1.38pF	1.52pF	NA	NA	NA
	C_package	0.12pF	0.13pF	0.13pF	NA	NA	NA
	C_total	1.37pF	1.51pF	1.65pF	1.49pF	1.5pF	1.51pF

Insert component name here **MT47H128M8HQ**

		IBIS			Measured		
		min	Typ	max	min	typ	max
<b>DQ</b>	C_comp	3.06pF	3.24pF	3.47pF	NA	NA	NA
	C_package	0.09pF	0.13pF	0.17pF	NA	NA	NA
	C_total	3.15pF	3.37pF	3.64pF	3.2pF	3.36pF	3.56pF
<b>INPUT</b>	C_comp	1.16pF	1.35pF	1.54pF	NA	NA	NA
	C_package	0.08pF	0.1pF	0.14pF	NA	NA	NA
	C_total	1.24pF	1.45pF	1.68pF	1.38pF	1.47pF	1.61pF
<b>CLK</b>	C_comp	1.25pF	1.38pF	1.52pF	NA	NA	NA
	C_package	0.12pF	0.13pF	0.13pF	NA	NA	NA
	C_total	1.37pF	1.51pF	1.65pF	1.55pF	1.55pF	1.55pF



Insert component name here **MT47H64M16HR**

		IBIS			Measured		
		min	Typ	max	min	typ	max
<b>DQ</b>	C_comp	3.06pF	3.24pF	3.47pF	NA	NA	NA
	C_package	0.12pF	0.15pF	0.18pF	NA	NA	NA
	C_total	3.18pF	3.39pF	3.65pF	3.3pF	3.44pF	3.6pF
<b>INPUT</b>	C_comp	1.16pF	1.35pF	1.54pF	NA	NA	NA
	C_package	0.11pF	0.13pF	0.16pF	NA	NA	NA
	C_total	1.27pF	1.48pF	1.70pF	1.43pF	1.49pF	1.57pF
<b>CLK</b>	C_comp	1.25pF	1.38pF	1.52pF	NA	NA	NA
	C_package	0.13pF	0.13pF	0.13pF	NA	NA	NA
	C_total	1.38pF	1.51pF	1.65pF	1.48pF	1.49pF	1.51pF

3. ☐ Compare ODT Data with Measurement

**Not available**

4. ☐ If measured clamp current data is available provide an IBIS and Silicon clamp comparison for all models


**Not available**

### **IBIS vs HSPICE Correlation**


1. ☒ For all output model or I/O model run hspice transient simulation using encrypted netlist and using IBIS model (b-element).
  - a. ☒ Use the below setup and node naming conventions for the Ibis and Hspice deck file (.sp file). Indicate and update the setup diagram if it is different. Indicate version of Hspice simulator used for simulation (**Hspice 2006.09**)
  - b. ☒ Run simulation for all corners cases

In the IBIS file typ and slow corner V-t curves in DQ\*\_667 models are shifted by -200ps and -500ps relative to strong corner v-t curve to contain all 3 corners within 1.5ns window. Typ and slow corner V-t curves in DQFULL\*\_1066 models are shifted by -300ps and -400ps relative to strong corner v-t curve to contain all 3 corners within 0.938ns window. Because of this shift the typ and slow corner input stimulus in IBIS simulation are delayed by the v-t shift time as mentioned above. This does not effect the accuracy of the IBIS data.


## i. DQFULL\_533 driving DQFULL\_533




## ii. DQFULL\_533 driving DQFULL\_ODT50\_533




### iii. DQFULL\_533 driving DQFULL\_ODT75\_533




### iv. DQFULL\_533 driving DQFULL\_ODT150\_533



## v. DQFULL\_667 driving DQFULL\_667




## vi. DQFULL\_667 driving DQFULL\_ODT50\_667







## vii. DQFULL\_800 driving DQFULL\_ODT75\_800




## viii. DQFULL\_667 driving DQFULL\_ODT150\_667




## ix. DQFULL\_1066 driving DQFULL\_1066




## x. DQFULL\_1066 driving DQFULL\_ODT50\_1066




## xi. DQFULL\_1066 driving DQFULL\_ODT75\_1066



## xii. DQFULL\_1066 driving DQFULL\_ODT150\_1066



## Setup



Driver and Receiver models used from u48b.ibs model (Temperature range-commercial)

Simulator- Synopsys Hspice 2006.09

## Comments:

### Document Revision history

Rev 1.0- 11/14/2006